


# **ROLLER**



**GENiUS®**

**COMPANY  
WITH QUALITY SYSTEM  
CERTIFIED BY DNV  
= UNI EN ISO 9001/2000=**

**CE**

# ITALIANO

## AVVERTENZE PER L'INSTALLATORE

### OBLIGHI GENERALI PER LA SICUREZZA

**ATTENZIONE!** È importante per la sicurezza delle persone seguire attentamente tutta l'istruzione. Una errata installazione o un errato uso del prodotto può portare a gravi danni alle persone.

- Leggere attentamente le istruzioni prima di iniziare l'installazione del prodotto.
- I materiali dell'imballaggio (plastica, polistirolo, ecc.) non devono essere lasciati alla portata dei bambini in quanto potenziali fonti di pericolo.
- Conservare le istruzioni per riferimenti futuri.
- Questo prodotto è stato progettato e costruito esclusivamente per l'utilizzo indicato in questa documentazione. Qualsiasi altro utilizzo non esplicitamente indicato potrebbe pregiudicare l'integrità del prodotto e/o rappresentare fonte di pericolo.
- GENIUS declina qualsiasi responsabilità derivata dall'uso improprio o diverso da quello per cui l'automaticismo è destinato.
- Non installare l'apparecchio in atmosfera esplosiva: la presenza di gas o fumi infiammabili costituisce un grave pericolo per la sicurezza.
- Gli elementi costruttivi meccanici devono essere in accordo con quanto stabilito dalle Norme EN 12604 e EN 12605.
- Per i Paesi extra-CEE, oltre ai riferimenti normativi nazionali, per ottenere un livello di sicurezza adeguato, devono essere seguite le Norme sopra riportate.
- GENIUS non è responsabile dell'inosservanza della Buona Tecnica nella costruzione delle chiusure da motorizzare, nonché delle deformazioni che dovessero intervenire nell'utilizzo.
- L'installazione deve essere effettuata nell'osservanza delle Norme EN 12453 e EN 12445. Il livello di sicurezza dell'automaticismo deve essere C+D.
- Prima di effettuare qualsiasi intervento sull'impianto, togliere l'alimentazione elettrica e scollegare le batterie.
- Prevedere sulla rete di alimentazione dell'automatica un interruttore onnipolare con distanza d'apertura dei contatti uguale o superiore a 3 mm. È consigliabile l'uso di un magneteotermico da 6A con interruzione onnipolare.
- Verificare che a monte dell'impianto vi sia un interruttore differenziale con soglia da 0,03 A.
- Verificare che l'impianto di terra sia realizzato a regola d'arte e collegarvi le parti metalliche della chiusura.
- L'automatica dispone di una sicurezza intrinseca antischiaffiamento costituita da un controllo di coppia. È comunque necessario verificarne la soglia di intervento secondo quanto previsto dalle Norme indicate al punto 10.
- Li dispositivi di sicurezza (norma EN 12978) permettono di proteggere eventuali aree di pericolo da Rischii meccanici di movimento, come ad Es. schiacciamento, convogliamento, cesolamento.
- Per ogni impianto è consigliato l'utilizzo di almeno una segnalazione luminosa nonché di un cartello di segnalazione fissato adeguatamente sulla struttura dell'infissi, oltre ai dispositivi citati al punto "16".
- GENIUS declina ogni responsabilità ai fini della sicurezza e del buon funzionamento dell'automatica, in caso vengano utilizzati componenti dell'impianto non di produzione GENIUS.
- Per la manutenzione utilizzare esclusivamente parti originali GENIUS.
- Non eseguire alcuna modifica sui componenti facenti parte del sistema d'automatica.
- L'installatore deve fornire tutte le informazioni relative al funzionamento manuale del sistema in caso di emergenza e consegnare all'Utente utilizzatore dell'impianto il libretto d'avvertenze allegato al prodotto.
- Non permettere ai bambini o persone di sostare nelle vicinanze del prodotto durante il funzionamento.
- L'applicazione non può essere utilizzata da bambini, da persone con ridotte capacità fisiche, mentali, sensoriali o da persone prive di esperienza o del necessario addestramento.
- Tenere fuori dalla portata dei bambini radiocomandi o qualsiasi altro datore di impulso, per evitare che l'automatica possa essere azionata involontariamente.
- Il transito fra le ante deve avvenire solo a cancello completamente aperto.
- L'utente utilizzatore deve astenersi da qualsiasi tentativo di riparazione o d'intervento e deve rivolgersi solo ed esclusivamente a personale qualificato GENIUS o centri d'assistenza GENIUS.
- Tutto quello che non è previsto esplicitamente in queste istruzioni non è permesso.

# ENGLISH

## IMPORTANT NOTICE FOR THE INSTALLER GENERAL SAFETY REGULATIONS

**ATTENTION!** To ensure the safety of people, it is important that you read all the following instructions. Incorrect installation or incorrect use of the product could cause serious harm to people.

- Carefully read the instructions before beginning to install the product.
- Do not leave packing materials (plastic, polystyrene, etc.) within reach of children as such materials are potential sources of danger.
- Store these instructions for future reference.
- This product was designed and built strictly for the use indicated in this documentation. Any other use, not expressly indicated here, could compromise the good condition/operation of the product and/or be a source of danger.
- GENIUS declines all liability caused by improper use or use other than that for which the automated system was intended.
- Do not install the equipment in an explosive atmosphere: the presence of inflammable gas or fumes is a serious danger to safety.
- The mechanical parts must conform to the provisions of Standards EN 12604 and EN 12605.
- For non-EU countries, to obtain an adequate level of safety, the Standards mentioned above must be observed, in addition to national legal regulations.
- GENIUS is not responsible for failure to observe Good Technique in the construction of the closing elements to be motorised, or for any deformation that may occur during use.
- The installation must conform to Standards EN 12453 and EN 12445. The safety level of the automated system must be C+D.
- Before attempting any job on the system, cut out electrical power and disconnect the batteries.
- The mains power supply of the automated system must be fitted with an all-pole switch with contact opening distance of 3mm or greater. Use of a 6A thermal breaker with all-pole circuit break is recommended.
- Make sure that a differential switch with threshold of 0.03 A is fitted upstream of the system.
- Make sure that the earthing system is perfectly constructed, and connect metal parts of the means of the closure to it.

- The automated system is supplied with an intrinsic anti-crushing safety device consisting of a torque control. Nevertheless, its tripping threshold must be checked as specified in the Standards indicated at point 10.
- The safety devices (EN 12978 standard) protect any danger areas against mechanical movement Risks, such as crushing, dragging, and shearing.
- Use of at least one indicator-light is recommended for every system, as well as a warning sign adequately secured to the frame structure, in addition to the devices mentioned at point "16".
- GENIUS declines all liability as concerns safety and efficient operation of the automated system, if system components not produced by GENIUS are used.
- For maintenance, strictly use original parts by GENIUS.
- Do not in any way modify the components of the automated system.
- The installer shall supply all information concerning manual operation of the system in case of an emergency, and shall hand over to the user the warnings handbook supplied with the product.
- Do not allow children or adults to stay near the product while it is operating.
- The application cannot be used by children, by people with reduced physical, mental, sensorial capacity, or by people without experience or the necessary training.
- Keep remote controls or other pulse generators away from children, to prevent the automated system from being activated involuntarily.
- Transit through the leaves is allowed only when the gate is fully open.
- The User must not in any way attempt to repair or to take direct action and must solely contact qualified GENIUS personnel or GENIUS service centres.
- Anything not expressly specified in these instructions is not permitted.

# FRANÇAIS

## CONSIGNES POUR L'INSTALLATEUR

### RÈGLES DE SÉCURITÉ

**ATTENTION!** Il est important, pour la sécurité des personnes, de suivre à la lettre toutes les instructions. Une installation erronée ou un usage erroné du produit peut entraîner de graves conséquences pour les personnes.

- Lire attentivement les instructions avant d'installer le produit.
- Les matériaux d'emballage (matière plastique, polystyrène, etc.) ne doivent pas être laissés à la portée des enfants car ils constituent des sources potentielles de danger.
- Conserver les instructions pour les références futures.
- Ce produit a été conçu et construit exclusivement pour l'usage indiqué dans cette documentation. Toute autre utilisation non explicitement indiquée pourrait compromettre l'intégrité du produit et/ou représenter une source de danger.
- GENIUS décline toute responsabilité qui dériverait d'un usage improprie ou différent de celui auquel l'automaticisme est destiné.
- Ne pas installer l'appareil dans une atmosphère explosive: la présence de gaz ou de fumées inflammables constitue un grave danger pour la sécurité.
- Les composants mécaniques doivent répondre aux prescriptions des Normes EN 12604 et EN 12605.
- Pour les Pays extra-CEE, l'obtention d'un niveau de sécurité approprié exige non seulement le respect des normes nationales, mais également le respect des Normes susmentionnées.
- GENIUS n'est pas responsable du non-respect de la Bonne Technique dans la construction des fermetures à motoriser, ni des déformations qui pourraient intervenir lors de l'utilisation.
- L'installation doit être effectuée conformément aux Normes EN 12453 et EN 12445. Le niveau de sécurité de l'automaticisme doit être C+D.
- Couper l'alimentation électrique et déconnecter la batterie avant toute intervention sur l'installation.
- Prévoir, sur le secteur d'alimentation de l'automaticisme, un interrupteur onnipolaire avec une distance d'ouverture des contacts égale ou supérieure à 3 mm. On recommande d'utiliser un magnétothermique de 6A avec interruption onnipolaire.
- Vérifier qu'il y ait, en amont de l'installation, un interrupteur différentiel avec un seuil de 0,03 A.
- Vérifier que la mise à terre est réalisée selon les règles de l'art et y connecter les pièces métalliques de la fermeture.
- L'automaticisme dispose d'une sécurité intrinsèque anti-érastement, formée d'un contrôle du couple. Il est toutefois nécessaire d'en vérifier le seuil d'intervention suivant les prescriptions des Normes indiquées au point 10.
- Les dispositifs de sécurité (norme EN 12978) permettent de protéger des zones éventuellement dangereuses contre les Risques mécaniques du mouvement, comme l'érastement, l'acheminement, le cisaillement.
- On recommande que toute installation soit doté au moins d'une signalisation lumineuse, d'un panneau de signalisation fixé, de manière appropriée, sur la structure de la fermeture, ainsi que des dispositifs cités au point "16".
- GENIUS décline toute responsabilité quant à la sécurité et au bon fonctionnement de l'automaticisme si les composants utilisés dans l'installation n'appartiennent pas à la production GENIUS.
- Utiliser exclusivement, pour l'entretien, des pièces GENIUS originales.
- Ne jamais modifier les composants faisant partie du système d'automaticisme.
- L'installateur doit fournir toutes les informations relatives au fonctionnement manuel du système en cas d'urgence et remettre à l'Usager qui utilise l'installation les "Instructions pour l'Usager" fournis avec le produit.
- Interdire aux enfants ou aux tiers de stationner près du produit durant le fonctionnement.
- Ne pas permettre aux enfants, aux personnes ayant des capacités physiques, mentales et sensorielles limitées ou dépourvues de l'expérience ou de la formation nécessaires d'utiliser l'application en question.
- Eloigner de la portée des enfants les radiocommandes ou tout autre générateur d'impulsions, pour éviter tout actionnement involontaire de l'automaticisme.
- Le transit entre les vantaux ne doit avoir lieu que lorsque le portail est complètement ouvert.
- L'utilisateur doit s'abstenir de toute tentative de réparation ou d'intervention et doit s'adresser uniquement et exclusivement au personnel qualifié GENIUS ou aux centres d'assistance GENIUS.
- Tout ce qui n'est pas prévu expressément dans ces instructions est interdit.

# ESPAÑOL

## ADVERTENCIAS PARA EL INSTALADOR

### REGLAS GENERALES PARA LA SEGURIDAD

**ATENCION!** Es sumamente importante para la seguridad de las personas seguir atentamente las presentes instrucciones. Una instalación incorrecta o un uso impropio del producto puede causar graves daños a las personas.

- Lean detenidamente las instrucciones antes de instalar el producto.

# INDEX

<b>1. DESCRIPTION AND TECHNICAL CHARACTERISTICS</b>	<b>page.7</b>
<b>2. DIMENSIONS</b>	<b>page.7</b>
<b>3. MAXIMUM USE CURVE</b>	<b>page.7</b>
<b>4. ELECTRIC EQUIPMENT (standard system)</b>	<b>page.7</b>
<b>5. INSTALLATION OF THE AUTOMATION SYSTEM</b>	<b>page.8</b>
<b>5.1. PRELIMINARY CHECKS</b>	<b>page.8</b>
<b>5.2. INSTALLATION OF LEAF SUPPORTING FOUNDATION BOX</b>	<b>page.8</b>
<b>5.3. SETTING UP THE GATE</b>	<b>page.9</b>
<b>5.4. INSTALLING THE OPERATOR</b>	<b>page.9</b>
<b>6. START-UP</b>	<b>page.10</b>
<b>7. TEST OF THE AUTOMATED SYSTEM</b>	<b>page.10</b>
<b>8. MANUAL OPERATION</b>	<b>page.10</b>
<b>9. RETURNING TO NORMAL OPERATION</b>	<b>page.10</b>
<b>10. SPECIAL APPLICATIONS</b>	<b>page.10</b>
<b>11. MAINTENANCE</b>	<b>page.10</b>
<b>12. REPAIRS</b>	<b>page.10</b>

## CE DECLARATION OF CONFORMITY FOR MACHINES (DIRECTIVE 98/37/EC)

**Manufacturer:** GENIUS S.p.A.

**Address:** Via Padre Elzi, 32 - 24050 - Grassobbio- Bergamo - ITALY

**Declares that:** Operator mod. **ROLLER / ROLLER LENTO / ROLLER 24** with 230 Vac power supply

- is built to be integrated into a machine or to be assembled with other machinery to create a machine under the provisions of Directive 98/37/EC;
- conforms to the essential safety requirements of the following EEC directives:
  - 2006/95/EC Low Voltage directive.
  - 2004/108/EC Electromagnetic Compatibility directive.

and also declares that it is prohibited to put into service the machinery until the machine in which it will be integrated or of which it will become a component has been identified and declared as conforming to the conditions of Directive 89/392/EEC and subsequent modifications assimilated in Italian National legislation under Presidential decree No.459 of 24 July 1996.

Grassobbio, 06 June 2008



Managing Director  
D. Gianantonio

### Notes on reading the instruction

Read this installation manual to the full before you begin installing the product.

The symbol  indicates notes that are important for the safety of persons and for the good condition of the automated system.

The symbol  draws your attention to the notes on the characteristics and operation of the product.

# AUTOMATION SYSTEMS ROLLER

The **ROLLER** automation system for swing gates is a geared motor. It is designed for underground installation and therefore does not alter the appearance of the leaf. The foundation box of the automation system comes ready to take an operator. The **ROLLER** electromechanical operator is irreversible, so it ensures a mechanical stop and eliminates the need to install an electric lock.

**The ROLLER automated systems were designed and manufactured to control access of vehicles. Avoid any other use whatever.**

## 1. DESCRIPTION AND TECHNICAL CHARACTERISTICS




Fig. 1

Model	Roller Lento	Roller 230V	Roller 115V	Roller 24V
Power supply (Vac) (Vdc)	230	115	24	
Power (W)	300	380	600	70
Current (A)	1.3	1.7	5.3	3
Thermal protection (°C)	140			/
Capacitor (μF)	12.5	30		/
Max torque (Nm)	250	330		300
Angular velocity (°/sec)	4	6	7	6
Max. leaf (m)	3.5 (110°) - 3 (180°) - 2 (140°)			
Leaf opening angle (°)	110 (140 and 180 with kit)			
Use type and frequency	S3 - 30%			100%
Minimum indicative hourly cycles	20 (110° e 180°) 36 (140°)	30 (110° e 180°) 50 (140°)	100 (110° e 180°) 170 (140°)	
Operating ambient temperature (°C)	-20 ÷ +55			
Operator weight (Kg)	26.5			
Protection class	IP67			
Operator dimensions (mm)	360 x 150 x 140			
Box dimensions	See figura 2			

## 2. DIMENSIONS





Fig. 2

## 3. MAXIMUM USE CURVE

The curve makes it possible to establish maximum work time (T) according to use frequency (F). With reference to IEC 34-1 standard, the ROLLER gearmotor operating at S3 service, can function at a use frequency of 30%. To ensure efficient operation, operate in the work range below the curve.

The curve is obtained at a temperature of 20°C. Exposure to the direct sun rays can reduce use frequency down to 20%.



### CALCULATION OF USE FREQUENCY

The percentage of effective work time (opening + closing) compared to total time of cycle (opening + closing + pause times).

Calculation formula:

$$\% F = \frac{T_a + T_c}{T_a + T_c + T_p + T_i} \times 100$$

where:


T<sub>a</sub> = opening time

T<sub>c</sub> = closing time

T<sub>p</sub> = pause time

T<sub>i</sub> = time of interval between two complete cycles

## 4. ELECTRIC EQUIPMENT (STANDARD SYSTEM)



- ① Operators ROLLER (require 2 junction boxes)
- ② Photocells
- ③ Control unit
- ④ Pushbutton
- ⑤ Flashing light

To lay electrical cables, use adequate rigid and/or flexible tubes.

Always separate low voltage accessories from those operating at 230/115 V~. To avoid any interference, always use separate sheaths.

## 5. INSTALLATION OF THE AUTOMATION SYSTEM

### 5.1. PRELIMINARY CHECKS

To ensure trouble-free operation, make sure that the gate (whether existing or yet to be installed) has the following specifications:

- max. weight of single leaf 500 Kg;
- Lmax. length of single gate leaf 3.5 m with levers for 110° opening;
- max. length of single gate leaf 3 m with levers for 180° opening;
- max. length of single gate leaf 2 m with levers for 140° opening;
- strong and rigid leaf frame;
- smooth gate movement, with no stiff points;
- min. clearance between bottom edge of gate and ground as in fig. 6a (where 's' = thickness of guide bracket);
- mechanical travel stops.

 If any welding or brazing has to be done on the gate, do this before installing the automation system.

 The condition of the gate directly affects the reliability and safety of the automation system.

### 5.2. INSTALLATION OF LEAF SUPPORTING FOUNDATION BOX

Proceed as instructed below:

- a. existing gate with fixed hinges:
- Remove the gate;
  - Remove the bottom hinge.

 If the gate cannot be removed, place blocks under its bottom edge to support it.

- b. existing gate with adjustable hinges:

- Remove the bottom hinge;
- Slacken off the top hinge;
- Swing the leaf around the axis of the top hinge (Fig. 4).




Fig. 4

- c. New gate to be installed:

- Fit just the top hinge. If possible use an adjustable hinge;

1. Dig out a hole for the foundation box as shown in Fig. 5.

 Depending on the nature of the ground, it may be necessary to cast a bed of quick-setting concrete at the bottom of the hole to avoid subsidence in future.




Fig. 5

2. Place the foundation box in the hole, respecting the dimensions given in Fig. 6a - 6b - 6c. The center of the pivot on the foundation box must be perfectly aligned with the leaf's axis of swing (Fig. 6a - 6b - 6c).

 Use of the gear plate for 180° opening allows the housing case to be embedded in any position. The alignment of the pin present on the case with the leaf's axis of rotation must be respected at all times (Fig. 6c).




Fig. 6a




Fig. 6b




Fig. 6c

3. Lay down a PVC tube of diameter 35 mm through which to pass a 4 core electrical cable. The tube must reach from the box the control unit (Fig. 7 rif. ①). Lay a second tube to drain off rain water, from the box to the nearest drain (Fig. 7 rif. ②).




Fig. 7

4. Fix the box in place with a casting of concrete.

### 5.3. SETTING UP THE GATE

**⚠ Wait for the cement to set before starting this operation.**

- Assemble the release levers on the support bracket, and fit the latter on the pivot in the foundation box, also inserting the ball supplied (Fig. 8).

**⚠ Grease both the pivot and the ball.**

**Do not lubricate the release system for any reason.**




Fig. 8

- Prepare the guide bracket, as follows:
  - use a "U" profile with dimensions indicated in Fig. 9;




Fig. 9

- ascertain the correct location of the leaf on the "U" profile with reference to the axis of rotation (Fig. 10a or 10b); seal the "U" profile on the post side with a plate, as shown in Fig. 10a or 10b.




Fig. 10a

Fig. 10b

- Carefully weld the guide bracket to the support bracket (Fig. 11).




Fig. 11

- Fit the gate into the guide bracket and fix the top hinge in place.

**⚠ To ensure trouble-free operation, do NOT weld the gate leaf to the guide bracket or to the support bracket.**

- Manually verify whether the gate opens and closes completely and smoothly, stopping at the mechanical travel stops.

### 5.4. INSTALLING THE OPERATOR

- Open the gate leaf.

- Place the operator on the fastening screws on the foundation box, and fix it by means of the nuts and washers supplied (fig. 13a and 13b).

**⚠ In order to determine the exact position of the operator with the levers for 110° and 140° opening, please refer to fig. 12. In any case the operator pinion must be on the opposite side of leaves opening direction.**




Fig. 12

- Manually close the leaf and fit the driving levers supplied, as shown in Fig. 13a.




Fig. 13a

**⚠ In order to determine the exact position of the operator, gear plate for 180° opening (Fig. 13b) and the required settings, please refer to the instructions enclosed.**




Fig. 13b



For systems with 110° and 140° opening it is possible to fit the (optional) open (Fig. 14 rif. ①) and close (Fig. 14 rif. ②) mechanical stops inside the housing case. For installation details, please refer to the relative instructions.





Fig. 14

**⚠ Grease the operator pinion and the fixing pivots of the two levers.**

**Do not oil the gears of the gear plate.**

**Do not lubricate the release system for any reason.**

- Fasten the box cover by means of the screws supplied (Fig. 15).



- Install the second operator, if required, repeating the operations described above.
- Install the electronic control unit, referring to the dimensions indicated in the relevant instructions.

## 6. START-UP

**⚠ Before attempting any work on the system or on the operator, always turn off power.**

Observe points 10, 11, 12, 13, 14 of the GENERAL SAFETY OBLIGATIONS. Observing the instructions in Fig.3, lay the raceways and make the electric connections of the control board to the selected accessories. Always separate power cables from control and safety cables (push-button, receiver, photocells, etc...). To prevent any electric noise whatever, use separate sheaths.

- Program the control board according to your needs observing the concerning instructions.
- Switch on power to the system and check the condition of the LEDs according to the table of the control board instructions.

## 7. TEST OF THE AUTOMATED SYSTEM

Check operating efficiency of the automated system and all accessories connected to it.

Hand the "User's Guide" page to the Client, explain correct operation and use of the operator and indicate the potentially dangerous areas of the automated system.

## 8. MANUAL OPERATION

Should the need arise to operate the gate manually because of a power failure or malfunction, the release device with key fitted on the support bracket (Fig. 1 rif. ⑥) makes it possible to release the system both from the inside and from the outside.

To operate the leaf manually, proceed as follows:

**⚠ Cut power to the system.**

- open the lid of the lock (Fig. 16 rif. ①)
- insert the release key in the lock (Fig. 16 rif. ②)
- turn the key in the direction of the post, as far as it will go (Fig. 16 rif. ③)
- pull the lever out (Fig. 16 rif. ④)
- operate the leaf manually.




Fig. 16

## 9. RETURNING TO NORMAL OPERATION

**⚠ To avoid an involuntary pulse from activating the gate during the manoeuvre, before re-locking the operator, switch off power to the system.**

- push the lever back into its home position (Fig. 17 rif. ①)
- insert the release key in the lock and turn it in the direction opposite the post, as far as it will go (Fig. 17 rif. ②)
- operate the leaf manually until the lock is engaged in the locking bracket (Fig. 17 rif. ③)
- close the lid of the lock.
- make sure that the gate cannot be moved manually.
- restore power to the system.




Fig. 17

## 10. SPECIAL APPLICATIONS

There are no special applications.

## 11. MAINTENANCE

To ensure correct long-term operation and a constant level of safety, we advise you to generally control the system at least every 6 months. In the "User's Guide" booklet, there is a form for recording jobs.

## 12. REPAIRS


**⚠ The User must not in any way attempt to repair or to take direct action and must solely contact qualified GENIUS personnel or GENIUS service centres.**

# **ROLLER**

**Guida per l'utente - User's guide**

**Instructions pour l'utilisateur - Guía para el usuario**

**Anweisungen für den Benutzer - Gebruikersgids**



**GENIUS®**

**COMPANY  
WITH QUALITY SYSTEM  
CERTIFIED BY DNV  
= UNI EN ISO 9001/2000=**

**CE**




Fig. 1




Fig. 2

**⚠ Read the instructions carefully before using the product, and keep them for future consultation**

**⚠ The User must not in any way attempt to repair or to take direct action and must solely contact qualified GENIUS personnel or GENIUS service centres.**

### GENERAL SAFETY REGULATIONS

If used correctly, the automation will ensure a high degree of safety.

Some simple rules regarding behaviour will avoid any accidental trouble:

- 1- Do not pass through the leaves while they are moving. Before passing through the leaves, wait until they are fully open.
- 2- Do not, on any account, stand between the leaves.
- 3- Do not stand near the automation and do not allow children and other people to stand there, especially while it is operating.
- 4- Keep remote controls or any other pulse generator well away from children to prevent the automation from being activated involuntarily.
- 5- Do not allow children to play with the automation.
- 6- The application cannot be used by children, by people with reduced physical, mental, sensorial capacity, or by people without experience or the necessary training.
- 7- Do not willingly obstruct movement of the leaves.
- 8- Do not allow branches or shrubs to interfere with leaf movement.
- 9- Keep illuminated signalling systems efficient and clearly visible.
- 10- Do not attempt to activate the leaves manually unless you have released them first of all.
- 11- In the event of a malfunction, release the leaves to allow access and wait for qualified personnel to take appropriate action.
- 12- After enabling manual operating mode, switch off the power supply to the system before restoring normal operating mode.
- 13- Do not make any alterations to the components of the automation.
- 14- The User must not in any way attempt to repair or to take direct action and must solely contact qualified GENIUS personnel or GENIUS service centres.
- 15- Call in qualified personnel at least every 6 months to check the efficiency of the automation, safety devices and earth connection.

### DESCRIPTION

These instructions apply to the following model:

#### ROLLER

The **ROLLER** automation system for swing gates is a geared motor. It is designed for underground installation and therefore does not alter the appearance of the leaf.

The foundation box of the automation system comes ready to take an operator.

The **ROLLER** electromechanical operator is irreversible, so it ensures a mechanical stop and eliminates the need to install an electric lock.

A manual release makes it possible to move the gate in the event of a power-cut or fault.

The operators are supervised by an electronic control unit, housed in a container adequately protected against atmospheric agents.

The leaves are normally in closed position.

When the electronic control unit receives an opening command by remote control or by any other pulse generator, it activates the operator to rotate the leaves until they are sufficiently open to provide access.

If automatic operating mode was set, the leaves close on their own after the selected pause time has elapsed.

If semi-automatic operating mode was set, a second pulse must be sent to allow the leaves to close again.

A stop pulse (if supplied) always stops movement.

For detail on operation of the automation under different operational logics, consult the installation technician.

The automations include safety devices (photocells, sensitive edges,...) which prevent the leaves from moving when there is an obstacle in the area they protect.

The light indicates that leaves are moving.

### MANUAL OPERATING MODE

Should the need arise to operate the gate manually because of a power failure or malfunction, the release device with key fitted on the support bracket makes it possible to release the system both from the inside and from the outside.

To operate the leaf manually, proceed as follows:

#### ⚠ Cut power to the system.

- open the lid of the lock (Fig. 1 rif. ①)
- insert the release key in the lock (Fig. 1 rif. ②)
- turn the key in the direction of the post, as far as it will go (Fig. 1 rif. ③)
- pull the lever out (Fig. 1 rif. ④)
- operate the leaf manually.

### RESTORING NORMAL OPERATING MODE

#### ⚠ To avoid an involuntary pulse from activating the gate during the manoeuvre, before re-locking the operator, switch off power to the system.

- push the lever back into its home position (Fig. 2 rif. ①)
- insert the release key in the lock and turn it in the direction opposite the post, as far as it will go (Fig. 2 rif. ②)
- operate the leaf manually until the lock is engaged in the locking bracket (Fig. 2 rif. ③)
- close the lid of the lock.
- make sure that the gate cannot be moved manually.
- restore power to the system.

**REGISTRO DI MANUTENZIONE / MAINTENANCE REGISTER / REGISTRE D'ENTRETIEN / REGISTRO DE MANTENIMIENTO / WARTUNGSPROGRAMM / ONDERHOUDREGISTER**

**Dati impianto / System data / Données de l'installation / Datos equipo / Daten der Anlage / Gegevens installatie**

Installatore / Installer / Installateur / Instalador / Monteur / Installateur	
Cliente / Customer / Client / Cliente / Kunde / Klant	
Tipo impianto / Type of system / Type d'installation / Tipo de equipo / Art der Anlage / Type installatie	
Matricola / Serial No. / N° de série / N° de serie / Seriennummer / Serienummer	
Data installazione / Installation date / Date d'installation / Fecha de instalación / Installationsdatum / Datum installatie	
Attivazione / Start-up / Activation / Activación / Inbetriebnahme / Activering	

**Configurazione impianto / System configuration / Configuration de l'installation / Configuración del equipo / Konfiguration der Anlage / Configuratie installatie**

<b>COMPONENTE / PART / COMPOSANT / COMPONENTE / BAUTEIL / ONDERDEEL</b>	<b>MODELLO / MODEL / MODÈLE / MODELO / MODELL / MODEL</b>	<b>MATRICOLA / SERIAL NUMBER / N° DE SERIE / N° DE SERIE / SERIENNUMBER / SERIENUMMER</b>
Operatore / Operator / Opérateur / Operador / Antrieb / Aandrijving		
Dispositivo di sicurezza 1 / Safety device 1 / Dispositif de sécurité 1 / Dispositivo de seguridad 1 / Sicherheitsvorrichtung 1 / Veiligheidsvoorziening 1		
Dispositivo di sicurezza 2 / Safety device 2 / Dispositif de sécurité 2 / Dispositivo de seguridad 2 / Sicherheitsvorrichtung 2 / Veiligheidsvoorziening 2		
Coppia fotocellule 1 / Pair of photocells 1 / Paire de photocellules 1 / Par de fotocélulas 1 / Fotozellenpaar 1 / Paar fotocellen 1		
Coppia fotocellule 2 / Pair of photocells 2 / Paire de photocellules 2 / Par de fotocélulas 2 / Fotozellenpaar 2 / Paar fotocellen 2		
Dispositivo di comando 1 / Control device 1 / Dispositif de commande 1 / Dispositivo de mando 1 / Schaltvorrichtung 1 / Bedieningsvoorziening 1		
Dispositivo di comando 2 / Control device 2 / Dispositif de commande 2 / Dispositivo de mando 2 / Schaltvorrichtung 2 / Bedieningsvoorziening 2		
Radiocomando / Radio control / Radiocommande / Radiomando / Funksteuerung / Afstandsbediening		
Lampeggiante / Flashing lamp / Lampe clignotante / Destellador / Blinkleuchte / Signaallamp		

**Indicazione dei rischi residui e dell'uso improprio prevedibile / Indication of residual risks and of foreseeable improper use / Indication des risques résiduels et de l'usage impropre prévisible / Indicación de los riesgos residuos y del uso impropio previsible / Angabe der Restrisiken und der voraussehbaren unsachgemäßen Anwendung / Aanduiding van de restrisico's en van voorzienbaar oneigenlijk gebruik**


Nr	Data / Date / Date / Fecha / Datum / Datum	Descrizione intervento / Job description / Description de l'intervention / Descripción de la intervención / Beschreibung der Arbeiten / Beschrijving ingreep	Firme / Signatures / Signatures / Firma / Unterschrift / Handtekeningen
1			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
2			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
3			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
4			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
5			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
6			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
7			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
8			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
9			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant
10			Tecnico / Technician Technicien / Técnico Techniker / Technicus  Cliente / Customer Client / Cliente Kunde / Klant

**NOTE - NOTES - NOTE - NOTAS - ANMERKUNG - OPMERKINGEN**

**NOTE - NOTES - NOTE - NOTAS - ANMERKUNG - OPMERKINGEN**

**NOTE - NOTES - NOTE - NOTAS - ANMERKUNG - OPMERKINGEN**

**NOTE - NOTES - NOTE - NOTAS - ANMERKUNG - OPMERKINGEN**

Le descrizioni e le illustrazioni del presente manuale non sono impegnative. GENIUS si riserva il diritto, lasciando inalterate le caratteristiche essenziali dell'apparecchiatura, di apportare in qualunque momento e senza impegnarsi ad aggiornare la presente pubblicazione, le modifiche che essa ritiene convenienti per miglioramenti tecnici o per qualsiasi altra esigenza di carattere costruttivo o commerciale.

The descriptions and illustrations contained in the present manual are not binding. GENIUS reserves the right, while leaving the main features of the equipment unaltered, to undertake any modifications to hold necessary for either technical or commercial reasons, at any time and without revising the present publication.

Les descriptions et les illustrations du présent manuel sont fournies à titre indicatif. GENIUS se réserve le droit d'apporter à tout moment les modifications qu'elle jugera utiles sur ce produit tout en conservant les caractéristiques essentielles, sans devoir pour autant mettre à jour cette publication.

Las descripciones y las ilustraciones de este manual no comportan compromiso alguno. GENIUS se reserva el derecho, dejando inmutadas las características esenciales de los aparatos, de aportar, en cualquier momento y sin comprometerse a poner al día la presente publicación, todas las modificaciones que considere oportunas para el perfeccionamiento técnico o para cualquier otro tipo de exigencia de carácter constructivo o comercial.

Die Beschreibungen und Abbildungen in vorliegendem Handbuch sind unverbindlich. GENIUS behält sich das Recht vor, ohne die wesentlichen Eigenschaften dieses Gerätes zu verändern und ohne Verbindlichkeiten in Bezug auf die Neufassung der vorliegenden Anleitungen, technisch bzw. konstruktiv / kommerziell bedingte Verbesserungen vorzunehmen.

De beschrijvingen in deze handleiding zijn niet bindend. GENIUS behoudt zich het recht voor op elk willekeurig moment de veranderingen aan te brengen die het bedrijf nuttig acht met het oog op technische verbeteringen of alle mogelijke andere productie- of commerciële eisen, waarbij de fundamentele eigenschappen van het apparaat gehandhaafd blijven, zonder zich daardoor te verplichten deze publicatie bij te werken.

**Timbro rivenditore: / Distributor's stamp: / Timbre de l'agent: / Sello del revendedor: / Fachhändlerstempel: / Stempel dealer:**



**GENIUS®**

Via Padre Elzi, 32  
24050 - Grassobbio  
BERGAMO-ITALY  
tel. 0039.035.4242511  
fax. 0039.035.4242600  
[info@geniusg.com](mailto:info@geniusg.com)  
[www.geniusg.com](http://www.geniusg.com)

