

Boss BHT1 Coding Instructions



Key-Ring 310MHz Remote Control Transmitter


OVERHEAD DOOR OPENER

1. Remove 2 screws located at rear of opener & let case hinge down.

2. Locate grey coloured box and remove window to access program switch

RECEIVER BOX WITH WINDOW OPEN

Program Switch




ROLLER DOOR OPENER

1. Remove Box from the wall by lifting off screws

2. Locate Program Switch on rear of box.

REAR OF CONTROL BOX

Program Switch



Coding

1. With the power on push down on program switch until yellow LED is on & let go of switch
2. Push the button you want to open the door on the new remote – Green LED will blink – push the same button again to confirm – Green LED is now steady.
3. Wait 5 seconds – Yellow LED will go off & programming is complete. Replace window & refit.



Replacement Remotes - BUTTONS 1 – 4 are coded differently so 4 devices can be controlled Ignore symbols on buttons